




Kraus & Naimer

www.kraus-naimer.org.cn



C / CA / CH / CG 系列 开关接线图

电子手册



Kraus & Naimer

<https://www.kraus-naimer.org.cn>

开关接线图

电子手册

本手册旨在帮助我们的客户选择最常用的凸轮开关。它包含 Kraus & Naimer C、CA、CG 和 CH 系列凸轮开关的标准触点排列。

有关特殊或非标准开关的详细信息，请联系我们当地的销售办事处。

内容

		Code- no.	Stages C/CG/CH	Page
ON/OFF Switches 0-1				
60° Switching	1 pole	A200	1	32
	2 pole	A201	1	32
	3 pole	A202	2	32
	4 pole	A203	2	32
	5 pole	WAA341	3	56
	6 pole	A342	3	56
	7 pole	A343	4	56
	8 pole	A344	4	56
	9 pole	WAA345	5	56
	10 pole	A346	5	56
	11 pole	WAA347	6	56
	12 pole	A348	6	56
90° Switching	1 pole	A290	1	45
	2 pole	A291	1	45
	3 pole	A292	2	45
	4 pole	A324	2	54
4. Pole preclose 30°	4 pole	A293	2	45
	5 pole	A325	3	54
	6 pole	A326	3	54
30° Switching with spring return	1 pole	A204	1	32
	2 pole	A205	1	32
	3 pole	WAA206	2	32
	4 pole	WAA207	2	32
Double-throw Switches	1 pole	A220	1	36
	2 pole	A221	2	36
	3 pole	A222	3	36
	4 pole	A223	4	36
without „OFF“ Positions (1-2)	5 pole	A369	5	58
60° Switching	6 pole	A370	6	58
	7 pole	A371	7	58
	8 pole	A372	8	58
	9 pole	WAA373	9	58
	10 pole	WAA374	10	58
	11 pole	WAA375	11	58
	12 pole	WAA376	12	58

内容

Double-throw Switches		Code- no.	Stages C/CG/CH	Page
without „OFF“ (1-2)	1 pole	A720	1	83
with electrically	2 pole	A721	2	83
isolated contacts	3 pole	A722	3	83
	4 pole	A723	4	83
without „OFF“	1 pole	A295	1	47
with spring return	2 pole	A296	2	47
30° Switching	3 pole	WAA297	3	47
with electrically	1 pole	A795	1	86
isolated contacts				
with „OFF“	1 pole	A210	1	33
Positions (1-0-2)	2 pole	A211	2	33
60° Switching	3 pole	A212	3	33
	4 pole	A213	4	33
	5 pole	A361	5	57
	6 pole	A362	6	57
	7 pole	WAA363	7	57
	8 pole	WAA364	8	57
with electrically	1 pole	A710	1	81
isolated contacts	2 pole	A711	2	81
	3 pole	A712	3	81
	4 pole	A713	4	81
Positions (1-0-2)	1 pole	A218	1	35
90° Switching	2 pole	A219	2	35
	3 pole	WAA299	3	48
KG-, KH-, KF-Serie	3 pole	K900		88
1 Pol preclose 30°	4 pole	WAA294	4	44
KG-, KH-, KF-Serie,	4 pole	K950		88
4. pole preclose 30°				
Positions (1-0-2)	1 pole	A214	1	34
30° with spring return	2 pole	A215	2	34
to center	3 pole	A216	3	34

内容

Code- no.	Stages C/CG/CH	Page
--------------	-------------------	------

Double-throw Switches

with electrically	1 pole	A714	1	82
isolated contacts	2 pole	A715	2	82
Positions (1-0-2)	1 pole	A320	1	53
with spring return from left to center	2 pole	A321	3	52
from 1 to 0	3 pole	A322	2	53

Multi-step Switches without „OFF“ position

1 pole	3 Step	60°	A230	2	38
	4 Step	60°	A231	2	38
	5 Step	60°	A232	3	38
	6 Step	60°	A233	3	38
	7 Step	45°	WAA234	4	38
	8 Step	45°	WAA236	4	38
	9 Step	30°	WAA236	5	38
	10 Step	30°	WAA237	5	38
	11 Step	30°	WAA239	6	38
	12 Step	30°	WAA239	6	38
2 pole	3 Step	60°	A250	3	41
	4 Step	50°	A251	4	41
	5 Step	60°	A252	5	41
	6 Step	60°	WAA253	6	41
	7 Step	45°	WAA254	7	41
	8 Step	45°	WAA255	8	41
3 pole	3 Step	60°	A270	5	43
	4 Step	60°	A271	6	43
	5 Step	60°	WAA272	8	43
	6 Step	60°	WAA273	9	43
	7 Step	45°	WAA274	11	43
	8 Step	45°	WAA275	12	43
4 pole	3 Step	60°	A476	6	71
	4 Step	60°	A477	8	71
	5 Step	60°	WAA478	10	71

Contents

			Code- no.	Stages C/CG/CH	Page
Multi-step Switches without „OFF“ position					
5 pole	3 Step	60°	WAA484	8	73
	4 Step	60°	WAA485	10	73
6 pole	3 Step	60°	WAA489	9	75
	4 Step	60°	WAA490	12	75
and electrically isolated contacts					
1 pole	3 Step	60°	A730	2	82
	4 Step	60°	A731	2	85
2 pole	3 Step	60°	A750	3	84
	4 Step	60°	A751	4	85
Multi-step Switches with „OFF“ position					
1 pole	2 Step	60°	A240	1	38
	3 Step	45°	A242	2	39
	4 Step	30°	A242	2	39
	5 Step	30°	A243	3	39
	6 Step	30°	A244	3	39
	7 Step	30°	WAA245	4	39
	8 Step	30°	WAA246	4	39
	9 Step	30°	WAA247	5	39
	10 Step	30°	WAA248	5	39
	11 Step	30°	WAA249	6	39
2 pole	2 Step	50°	A260	2	42
	3 Step	45°	A261	3	42
	4 Step	30°	WAA262	4	42
	5 Step	30°	WAA263	5	42
	6 Step	30°	WAA264	6	42
	7 Step	30°	WAA265	7	42
3 pole	2 Step	60°	A280	3	44
	3 Step	45°	A281	5	44
	4 Step	30°	WAA282	6	44
	5 Step	30°	WAA283	8	44
	6 Step	30°	WAA284	9	44

Contents

			Code- no.	Stages C/CG/CH	Page
Multi-step Switches with „OFF“ position					
4 pole	2 Step	60°	WAA480	4	72
	3 Step	45°	WAA481	6	72
	4 Step	30°	WAA482	8	72
5 pole	2 Step	60°	WAA486	5	74
	3 Step	45°	WAA487	8	74
6 pole	2 Step	60°	WAA491	6	75
General Application Switches					
2 Gang	1 pole	60°	A310	1	49
Switching sequence:	2 pole	60°	A312	2	50
0, A, A+B	3 pole	60°	WAA314	3	51
3 Gang	1 pole	30°	A311	2	49
Switching sequence:	2 pole	30°	WAA313	3	50
0, A, A+B, A+B+C	3 pole	30°	WAA315	5	52
General Application Series - Switching					
2 Gang	1 pole	30°	WAA330	1	55
Switching sequence:	2 pole	30°	WAA331	2	55
0, A, B, A+B	3 pole	30°	WAA332	3	55
Coding Switches/Binary Code					
0 up to 7		30°	A540	2	76
0 up to 7 complement		45°	WAA541	2	76
0 up to 7+complement		45°	WAA542	3	77
0 up to 11		30°	A543	2	77
0 up to 11+complement		30°	WAA545	4	78
Coding Switches/BCD-Code					
0 up to 9		30°	A550	2	78
0 up to 9 complement		30°	WAA551	2	79
0 up to 9+complement		30°	WAA552	4	79

Contents

		Code- no.	Stages C/CG/CH	Page
Voltmeter-Double-throw Switches				
without „OFF“				
3 phase 3 wire	45°	A023	2	19
3 phase 3 wire and phase to neutral	45°	A025	3	19
with „OFF“				
3 phase 3 wire	45°	A004	2	14
3 phase to neutral	45°	WAA005	2	15
3 phase 3 wire and phase to neutral	45°	A007	3	16
2 separate 3 phase with „OFF“	45°	WAA008	4	17
Ammeter-Double-throw Switches				
with „OFF“				
1 pole 3 Current transformers	90°	A048	3	24
2 pole 2 Current transformers	90°	WAA037	3	21
2 pole 3 Current transformers	90°	A038	5	22
without „OFF“				
1 pole 3 Current transformers	90°	WAA017	3	18
1 pole 4 Current transformers	90°	WAA036	4	20
2 pole 4 Current transformers	90°	WAA039	6	23

Contents

			Code- no.	Stages C/CG/CH	Page
Control Switches					
Stop switch	1 pole	30°	WAA174	1	25
Start switch	1 pole	30°	A175	1	25
Stop start switch	1 pole	30°	A176	1	26
	2 pole	30°	WAA183	2	30
Stop start switch with spring return from start to run		90°+30°	A178	1	28
Double-Stop start switch with spring return from start to run		60°+30°	WAA177	2	27
for contactor interlock with spring return from start to run		60°+30°	WAA182	2	30
and electrically isolated contacts					
Stop start switch	1 pole	30°	A789	1	86
Stop start switch with spring return from start to run		90°+30°	A791	1	86
for 2 contactors, Contactor control with spring return to „OFF“		30°	WAA179	3	29
Main Switches 3, 4, 6, 8 pole, with and without auxiliary contacts					87

内容

		Code- no.	Stages C/CG/CH	Page
Motor Switches				
Motor Reversing Switches				
Position (1-0-2)	2 pole 60°	A400	2	59
	3 pole 60°	A401	3	59
with spring return to „OFF“	3 pole 30°	A228	3	37
Star-delta Switches				
Normal version	60°	A410	4	60
Reversing	45°	WAA413	5	61
with auxiliary contact, closed in „OFF“-Position	60°	WAA416	5	62
For use with contactors	90°	A419	4	62
Motor Control Switches				
Position (0-1-2)	60°	A440	4	64
without „OFF“	60°	A466	4	69
Position (1-0-2)	60°	A441	4	64
Reversing	45°	A442	6	65
for reversing for				
for use with contactors and	60°	WAA444	5	66
with slip clutch for „OFF“ load use	45°	WAA468	10*	70
Motor Control Switches				
2 speed, 2 winding				
0 - A - B, Y or Δ	60°	WAA451	3	67
3 speed, 2 winding				
0 - AΔ - BY - AY	45°	WAA457	6	68
Start and Run Switches				
Split-phase start	90°+30°	A425	2	63
Reversing				
Split-phase start	60°+30°	WAA426	3	63
Split-phase reversing				
auto cutout of start field	60°	A622	3	80
winding				


* with slip clutch

图形说明

Contactor or Relay 接触器或继电器	
Thermal Relay 热继电器	
Motor 电机	
Coil / Inductance 线圈/电感	
Ammeter 电流表	
Voltmeter 电压表	
Earth / Ground 地线/接地	
NO-contact 常开触点	
NC-contact 常闭触点	
Motor - star circuit 电机星形 (Y 形) 接法电路	
Motor - delta circuit 电机三角形 (Δ 形) 接法电路	
Motor - double star circuit 电机双星形 接法电路	

连接详细信息

信息以仅开关图或开关图和连接图（适当时）的形式呈现。





www.kraus-naimer.org.cn

A410 星三角切换开关



大图展示了开关图表。图表中某一列里的叉号表示，当开关处于该叉号左侧所示的位置时，其上方的触点处于闭合状态。例如，触点3/4在三角位置时闭合。两条或多条竖线表示在开关从一个位置移动到下一个位置的过程中，该触点保持闭合状态。右侧的图像展示了电源和负载的接线连接。例如，L1连接到开关端子1，而U1或T1连接到端子2。


电压切换开关



A004 Voltmeter Switch
3 phase 3 wire

电压切换开关



Standard face plate: F785		1	3	5	7	9	11
							
		2	4	6	8	10	12
L3-L1			X			X	
L2-L3			X	X			
L1-L2					X	X	
0							
L1-N						X	X
L2-N				X			
L3-N		X					X
A007							





www.kraus-naimer.org.cn

A007 Voltmeter Switch
3 phase to neutral

电压切换开关



Standard face plate: F788		1	3	5	7	9	11	13	15
									
		2	4	6	8	10	12	14	16
L3-L1			X				X		
L2-L3					X				X
L1-L2		X							X
0									
L1-L2		X						X	
L2-L3				X				X	
L3-L1		X				X			
WAA008									



www.kraus-naimer.org.cn

WAA008 Voltmeter Switch
(formerly A008) 2 separate 3 phase


电压切换开关




www.kraus-naimer.org.cn

WAA017 Ammeter Switch
1 pole, 3 Current transformers

电压切换开关




A023 Voltmeter Switch, 3 phase 3 wire



A025 Voltmeter Switch, 3 phase 3 wire,
3 phase to neutral



电流切换开关




www.kraus-naimer.org.cn

WAA036 Ammeter Switch
(formerly A036) 1 pole, 4 Current transformers

电流切换开关


Standard face plate: F057		1	3	5	7	9	11
							
		2	4	6	8	10	12
1		X			X	X	
		X	X		X		
0							
				X		X	X
2			X	X			X
WAA037							



www.kraus-naimer.org.cn

WAA037 Ammeter Switch
(formerly A037) 2 pole, 2 Current transformers



电流切换开关



www.kraus-naimer.org.cn


A038 Ammeter Switch
2 pole, 3 Current transformers

电流切换开关





WAA039 Ammeter Switch
(formerly A039) 2 pole, 4 Current transformers

电流切换开关




A048 Ammeter Switch
1 pole, 3 Current transformers

控制开关






A175 Start switch
1 pole



WAA174 Stop switch
(formerly A174) 1 pole

控制开关

Standard face plate: F024		1	3
			
		2	4
STOP			X
START			X
A176			






A176 Stop start switch

2 pole see page 31

Electrically isolated contacts see page 86



控制开关


Standard face plate: F121		1	3	5	7
					
START		2	4	6	8
1			X		X
0					X
2				X	
START		X			
WAA177					



WAA177 Stop Start Switch for two units
(formerly A177) 2 pole, with spring return from start to run


控制开关


Standard face plate: F119		1	3
			
		2	4
0			
1		X	X
START		X	X
A178			



A178 Stop start switch
 1 pole, with spring return from start to run
 Electrically isolated contacts see page 86



控制开关

Standard face plate: F02.5							
				1	3	5	7
							
				2	4	6	8
1					X	X	
0					X		
2					X		X
WAA179							




WAA179 Contactor control with spring return to „OFF“
(formerly A179)


控制开关



WAA182 Stop Start Switch
(formerly A182) with spring return to run with
contactor interlock




控制开关




WAA183 Stop start switch
(formerly A183) 2 pole

ON/OFF 开关

Standard face plate: F070		1	3	5	7
					
		2	4	6	8
0					
1		X	X	X	X
A200	1 pole				
A201	2 pole				
A202	3 pole				
A203	4 pole				

A200 up to A203
ON/OFF Switches,
60° Switching



ON/OFF Switches 5- up to 12 pole
see page 56

Standard face plate: F169		1	3	5	7
					
		2	4	6	8
0					
1		X	X	X	X
A204	1 pole				
A205	2 pole				
WAA206	3 pole				
WAA207	4 pole				

A204 up to WAA207
(formerly A207)

ON/OFF Switches
with spring return,
30° Switching

双掷开关

Standard face plate: F071		1	3	5	7	9	11	13	15
									
		2	4	6	8	10	12	14	16
1			X		X		X		X
0									
2		X		X		X		X	
A210	1 pole								
A211	2 pole								
A212	3 pole								
A213	4 pole								


www.kraus-naimer.org.cn

A210 up to A213 Double-throw Switches, with „OFF“, 60° Switching

Electrically isolated contacts see page 81

Double-throw Switches with „OFF“, 5-8 pole see page 57

双掷开关

Standard face plate: F025		1	3	5	7	9	11
							
		2	4	6	8	10	12
	1	X		X		X	
	0						
	2		X		X		X
A214	1 pole						
A215	2 pole						
A216	3 pole						

www.kraus-naimer.org.cn

A214 up to A216 Double-throw Switches with „OFF” and with spring return to „OFF”, 30° Switching

Electrically isolated contacts see page 82

双掷开关


Standard face plate: F057		1	3	5	7
Φ 0 1 —  — 2		 		 	
		2	4	6	8
1		X		X	
		X		X	
0					
2			X		X
			X		X
A218	1 pole				
A219	2 pole				

A218, A219

Double-throw Switches with „OFF“,
90° Switching

For 3 & 4 pole options see pages 48 & 46 respectively

双掷开关

Standard face plate: F072 		1	3	5	7	9	11	13	15
									
		2	4	6	8	10	12	14	16
1		X		X		X		X	
2			X		X		X		X
A220	1 pole								
A221	2 pole								
A222	3 pole								
A223	4 pole								


A220 up to A223

Double-throw Switches without „OFF“,
60° Switching

Electrically isolated contacts see page 83

Double-throw Switches without „OFF“ 5-12 pole see page 58

电机马达开关



A228 Motor Reversing Switches
3 pole, with spring return to 0

3 Step A230 *



8 Step WAA235 (formerly A235)



4 Step A231 **



9 Step WAA236 (formerly A236)



5 Step A232



10 Step WAA237 (formerly A237)



6 Step A233



11 Step WAA238 (formerly A238)



7 Step WAA234 (formerly A234)



12 Step WAA239 (formerly A239)



Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

and electrically isolated contacts see *Page 84 resp. **Page 85

多级开关 1 pole without „OFF“

多级开关 1 pole with „OFF“


2 Step	A240	
3 Step	A241	
4 Step	A242	
5 Step	A243	
6 Step	A244	
7 Step	WAA245 (formerly A245)	

Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

多级开关 1 pole with „OFF“


8 Step

WAA246
(formerly A246)



9 Step

WAA247
(formerly A247)




10 Step

WAA248
(formerly A248)




11 Step

WAA249
(formerly A249)



Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

多级开关 2 pole without „OFF“



Electrically isolated contacts see *Page 84 resp. **Page 85

Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.


多级开关 2 pole with „OFF“

2 Step	A260	
3 Step	A261	
4 Step	WAA262 (formerly A262)	
5 Step	WAA263 (formerly A263)	
6 Step	WAA264 (formerly A264)	
7 Step	WAA265 (formerly A265)	


Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

多级开关 3 pole without „OFF“


3 Step
A270




4 Step
A271




5 Step
WAA272
(formerly A272)




6 Step
WAA273
(formerly A273)



7 Step
WAA274
(formerly A274)




8 Step
WAA275
(formerly A275)




Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

多级开关 3 pole with „OFF“


2 Step
A280




3 Step
A281




4 Step
WAA282
(formerly A282)



5 Step
WAA283
(formerly A283)





6 Step
WAA284
(formerly A284)






Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

ON/OFF 开关

Standard face plate: F056		1	3	5	7
					
		2	4	6	8
0					
					X
		X	X	X	
1		X	X	X	X
A290	1 pole				
A291	2 pole				
A292	3 pole				
A293	4 pole, 1 Pole preclose				



A290 up to A293
ON/OFF Switches 90° Switching

双掷开关

Standard face plate: F057		1	3	5	7	9	11	13	15
									
		2	4	6	8	10	12	14	16
1		X		X		X		X	
		X		X		X			
								X	
0									
									X
			X		X		X		
2			X		X		X		X
WAA294		4 pole, 1 Pole preclose							

WAA294 Double-throw Switch with „OFF“,
(formerly A294) 90° Switching


双掷开关

Standard face plate: F026		1	3	5	7	9	11
							
		2	4	6	8	10	12
 1		X		X		X	
 2			X		X		X
A295	1 pole						
A296	2 pole						
WAA297	3 pole						

A295* up to WAA297 (formerly A297)
 Double-throw Switches without „OFF“,
 with spring return, 30° Switching



*Electrically isolated contacts see page 86

双掷开关



Standard face plate: F057		1	3	5	7	9	11
							
		2	4	6	8	10	12
1		X		X		X	
		X		X		X	
0							
2			X		X		X
			X		X		X
WAA299							

WAA299 Double-throw Switch with „OFF“
 (formerly A299) 90° Switching, 3 pole

通用型开关




A310 General Application Switch
2 Gang, 1 pole
0, A, A+B




A311 General Application Switch
3 Gang, 1 pole
0, A, A+B, A+B+C

通用型开关






A312 General Application Switch
2 Gang, 2 pole
0, A, A+B



WAA313 General Application Switch
(formerly A313) 3 Gang, 2 pole
0, A, A+B, A+B+C


通用型开关



Standard face plate: F075					
					
1	3	5	7	9	11
					
2	4	6	8	10	12
					
					
0					
1					
2					
WAA314					


WAA314 General Application Switch
(formerly A314) 2 Gang, 3 pole
0, A, A+B

通用型开关



WAA315 General Application Switch
 (formerly A315) 3 Gang, 3 pole
 0, A, A+B, A+B+C



双掷开关

Standard face plate: F341 		1	3	5	7	9	11
		2		6		10	
		4		8		12	
	1		X		X		X
	0						
	2	X		X		X	
A320	1 pole						
A321	2 pole						
A322	3 pole						

A320 up to A322



Double-throw Switches with „OFF“ with spring return from left to center


ON/OFF 开关

Standard face plate: F056 		1	3	5	7	9	11
							
		2	4	6	8	10	12
0							
		X	X	X	X	X	X
1		X	X	X	X	X	X
A324	4 pole						
WAA325	5 pole						
A326	6 pole						

A324 up to A326
ON/OFF Switches, 90° Switching


双联串联开关

Standard face plate: F001											
											
											
0											
1		X						X			
2								X			X
3		X						X			X
WAA330	1 pole										
WAA331	2 pole										
WAA332	3 pole										



WAA330 up to WAA332 2 Gang Series Switching
(formerly A330 up to A332) 0,A,B,A+B

ON/OFF 开关



WAA341 (formerly A341) 5 pole

A342 6 pole

A343 7 pole

A344 8 pole

WAA345 (formerly A345) 9 pole


A346 10 pole

WAA347 (formerly A347) 11 pole

A348 12 pole




ON/OFF Switches, 60° Switching

双掷开关



Double-throw Switches with „OFF“ 60° Switching

A361	5 pole	WAA363 (formerly A363)	7 pole
A362	6 pole	WAA364 (formerly A364)	8 pole



Double-throw Switches without „OFF“, 60° Switching

A369 5 pole A371 7 pole

WAA373 9 pole WAA375 11 pole
(formerly A373) (formerly A375)



A370 6 pole A372 8 pole

WAA374 10 pole WAA376 12 pole
(formerly A374) (formerly A376)

双掷开关

电机开关


Standard face plate: F071		1	3	5	7	9	
		2	4	6	8	10	
1			X	X		X	
0							
2		X			X	X	
A400		2 pole					
A401		3 pole					




A400, A401 Motor Reversing Switches

With spring return to „OFF“ see page 37

电机开关






电机开关



WAA413 Star-delta Switch
(formerly A413) Reversing

电机开关




Star-delta Switches


WAA416 With auxiliary contact, (formerly A416) closed in „OFF“ position

A419 For use with reversing contactors

电机开关



A425 Start and Run Switch
Split-phase start



WAA426 Start and Run Switch
(formerly A426) Split-phase start reversing

Standard face plate: F073															
1 0 Φ 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															
1 2 1 2															

A440 2 speed, single winding


0 - AΔ - AΥ


A441 AΔ - 0 - AΥ

without „OFF“ see page 69

电机开关




电机开关

Standard face plate: F105													
													
		2	4	6	8	10	12	14	16	18	20	22	24
2			X	X			X	X			X	X	
1			X	X				X	X			X	
0													
1					X			X	X			X	
2		X			X		X				X	X	X
A442		X											




A442 2 speed, single winding with reverse
 $A\overline{Y}\overline{Y} - A\Delta - 0 - A\Delta - A\overline{Y}\overline{Y}$


电机开关

Standard face plate: F073											
											
1	3	5	7	9	11						
2	4	6	8	10	12						
0						X	X	X	X	X	X
1						X	X	X	X	X	X
2						X	X	X	X	X	X
WAA451											


WAA451 Motor Control Switch
 (formerly A451) 2 speed, 2 winding
 0 - A - B, Y or Δ




电机开关

Standard face plate: F109										23
										
1	3	5	7	9	11	13	15	17	19	
										
2	4	6	8	10	12	14	16	18	20	24
0										
1				X	X			X		
2	X	X								X
3			X	X			X	X	X	
WAA457										

WAA457 Motor Control Switch
 (formerly A457) 3 speed, 2 winding
 0 - AΔ - BΥ - AΥ



电机开关




A466 2 speed, single winding without „OFF“
 Δ - Υ

多级开关 4 pole without „OFF“


3 Step

A476




4 Step

A477



5 Step WAA478

(formerly A478)




Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

多级开关 4 pole with „OFF“


2 Step



3 Step




4 Step




Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.

**多级开关 5 pole
without „OFF“**





3 Step WAA484 (formerly A484)



4 Step WAA485 (formerly A485)

Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate.


多级开关 5 pole with „OFF“




Numbers shown at the connection points on the above diagrams, correspond to the terminal numbers on the switch. The position of connection points correspond to the positions indicated on the face plate

多级开关 6 pole


without „OFF“



编码开关/二进制码

Standard face plate: F322				1	3	5
						
				2	4	6
				X	X	X
				X	X	X
				X	X	X
				X	X	X
				X	X	X
				X	X	X
WAA541						

WAA541 0-7 +complement
(formerly A541)



Standard face plate: F322				1	3	5
						
				2	4	6
				X	X	X
				X	X	X
				X	X	X
				X	X	X
				X	X	X
				X	X	X
A540						

A540 0-7

编码开关/二进制码



Standard face plate: F007				1	3	5	7
							
0				2	4	6	8
1				X			
2					X		
3				X	X		
4						X	
5				X			
6					X	X	
7				X	X	X	
8							X
9				X			X
A550							

A550 0-9


Standard face plate: F009				1	3	5	7	9	11	13	15
											
0				2	4	6	8	10	12	14	16
1				X				X	X	X	X
2					X				X		
3				X	X					X	
4						X			X	X	
5				X				X	X		
6					X	X					
7				X	X	X				X	
8							X	X	X		
9				X					X		
10					X					X	
11				X	X		X				X
WAA545											

WAA545 0-11+complement
(formerly A545)

编码开关/二进制码


Standard face plate: F007				1	3	5	7
							
				2	4	6	8
				X	X	X	X
					X		
						X	
					X	X	
						X	
					X		
						X	X
WAA551							

WAA551 0-9
(formerly A551)

Standard face plate: F007															
															
WAA552															

WAA552 0-9+complement
(formerly A552)


电机开关



WAA622
(formerly A622)



Start and Run Switch
Split-phase reversing
auto cutout of start
field winding

具有电气隔离触点的双掷开关

Standard face plate: F071		1	3	5	7	9	11	13	15
									
		2	4	6	8	10	12	14	16
1			X		X		X		X
0									
2		X		X		X		X	
A710	1 pole								
A711	2 pole								
A712	3 pole								
A713	4 pole								


A710 up to A713 Double-throw Switch
with „OFF“, 60° Switching

具有电气隔离触点的双掷开关

Standard face plate: F025 		1	3	5	7
					
		2	4	6	8
	1	X		X	
	0				
	2		X		X
A714	1 pole				
A715	2 pole				

A714 up to A715 Double-throw Switch
with „OFF“ with spring return
to center, 30° Switching



具有电气隔离触点的双掷开关

Standard face plate: F072		1	3	5	7	9	11	13	15
									
		2	4	6	8	10	12	14	16
1		X		X		X		X	
2			X		X		X		X
A720	1 pole								
A721	2 pole								
A722	3 pole								
A723	4 pole								

A720 up to A723

Double-throw Switch without „OFF“,
60° Switching


具有电气隔离触点的多档位开关

Standard face plate: F076 		1	3	5	7	9	11
							
		2	4	6	8	10	12
1		X				X	
2			X				X
3				X	X		
A730	1 pole						
A750	2 pole						

A730, A750

Multi-step Switch without „OFF“, 3 Positions


具有电气隔离触点的多档位开关

Standard face plate: F077		1	3	5	7	9	11	13	15
									
		2	4	6	8	10	12	14	16
1		X				X			
2				X				X	
3					X				X
4			X				X		
A731	1 pole								
A751	2 pole								


A731, A751

Multi-step Switch without „OFF“, 4 Positions


具有电气隔离触点的控制开关



A789 Stop start switch



A791 Stop start switch
with spring return
from start to run




A795 Double-throw Switch
without „OFF“,
1 pole with spring return


KG-, KH- KF-系列主开关




3 pole




4 pole (3+N)




3 pole, 1NO+1NC




4 pole, 1NO+1NC



6 pole





6 pole, 1NO+1NC



8 pole

KG-、KH-和KF-系列带 “ OFF ”位的双投开关





Kraus & Naimer

www.kraus-naimer.org.cn

© Kraus & Naimer 01/2025